

SPECIAL CARE ADHESIVE P10

Two-component transparent, polymerising adhesive. This adhesive is a viscous solution of PMMA in MMA monomer. A catalyst (Special Care Additive B), added at the time of use, causes the monomer to polymerise as PMMA.

PROPERTIES

Viscosity at 20°C (Brookfield)	Density at 20°C	Flash point	Solids content	Storage temperature	Colour
1200 - 1800 mPa.s	1.05 g/cm ³	10°C	≈ 31%	Maximum 30°C	Transparent with a light violet tint

APPLICATIONS

- For bonding ALTUGLAS™ CN and EX in a range of applications such as POS displays, signs display cases, etc.
- This adhesive can also be used for bonding other plastic materials, such as polystyrene and ABS, after they have first been annealed as a precaution
- In such cases, prior testing is recommended.
- In order to achieve optimum adhesion, the adhesive joint should be between 0.5mm and 1mm thick.
- For assembling angles, ALTUGLAS™ edges should be chamfered.

TYPES OF BOND

- Edge-to-edge bonding (cases, boxes).
- Angled bonding with chamfered edges (POS displays)
- Edge-to-surface bonding (raised lettering on signs).
- Surface-to-surface bonding (chessboards, decorative panels, flat lettering).
- This list of examples is not exhaustive.

STORAGE PRECAUTIONS

Unopened packages should be stored in a cool, dry, well-ventilated place. If stored unopened, in their original packaging, hermetically sealed and at a temperature between 8°C and 30°C, Special Care Adhesive P10 and Special Care Additive B can be kept for up to two years from the date of packaging.

PRECAUTIONS IN USE

- We strongly recommend that receptacles be closed tightly as soon the required quantity has been taken. Use precision equipment to weigh the adhesive and the catalyst: 4 parts Special Care Additive B to 100 parts Special Care Adhesive P10, by mass or volume.
- Fit a protective cap to applicator tubes to avoid them becoming blocked and do not leave adhesive in the tubes for more than 10 minutes.
- Do not apply if the temperature is lower than 1°C, in a damp atmosphere or to a damp surface.

TOXICITY AND SAFETY

- Special Care Adhesive P10 contains MMA, which is highly flammable and its vapour can cause irritation to the skin, eyes and respiratory tract
 - Do not inhale the vapour.
 - Work in a well ventilated area.
 - Avoid contact with the skin and eyes
- Special Care Adhesive P10 has a closed-vessel flash point of 10°C, which makes it flammable.
- Store well away from heat and any source of ignition.
- Do not smoke whilst using the product.
- Special Care Additive B can irritate the eyes and respiratory tract. Avoid all contact with the eyes and mucous membranes.
- For further information, see the Safety Data Sheet for each component.

PACKAGING

- Special Care Adhesive P10 is supplied in full cartons containing 12 bottles of 500g or 1kg, and also in individual canisters of 10kg. Full cartons cannot be split. Bottles are made from aluminium for safety and corrosion reasons. Each individual package is labelled with important information from the safety data sheet and the production batch number.
- Special Care Additive B is packaged separately but supplied with Altuglas™ Adhesive P10.

TECHNICAL DATA SHEET

GUIDELINES FOR USE

Releasing internal strains:

The ALTUGLAS™ CN and EX to be glued can be subject to internal strains caused by various machining or forming operations. Such strains must therefore be released, otherwise cracking (crazing) will occur on contact with solvents in the adhesive. If machining (cutting or milling) operations have been performed with efficient cooling (clean water, or water + air), the edges need only be sanded off before bonding.

Disc polishing, forming and hot-bending result in an increased risk of crazing, which justifies stoving (see ALTUGLAS™ Technical Brochure).

With laser cutting and flame polishing, it is essential that the parts be annealed before any attempt at bonding.

Preparation of surfaces:

Polymerising adhesives work by adding material and can compensate for any roughness. The surfaces of the joint should preferably be roughened to increase the contact area. Previously machined edges should be dry-sanded and smooth surfaces roughened with sandpaper.

The surfaces to be bonded must be completely dry and clean. Remove all traces of grease from the parts to be glued using petroleum ether or a 50/50 mixture of water/methylated spirit.

If necessary, areas adjacent to the area being bonded can be protected by a special adhesive-resistant tape (e.g. polypropylene). If necessary, pre-assemble the parts using the same adhesive tape.

Applying the adhesive.

After incorporating and mixing the Additive B catalyst, close the mixing vessel and let it stand for 5 to 10 minutes to allow any air bubbles to escape naturally. Do not shake at this stage. The adhesive is then usable for about 30 minutes.

When pre-assembling, adhesive may be applied to the joint area using a syringe or polyethylene bottle fitted with a nozzle. Other means, such as coating by casting, can be used for large surfaces. Joints should be kept under pressure by moderate clamping at between 50 and 300 g/cm².

Drying and hardening time:

The external surface of glued joints will dry in approximately 2 hours at 20°C (guide time). Hardening varies with thickness, temperature and humidity.

It is usually possible to handle glued objects (carefully) after 2 to 3 hours but a minimum of 24 hours must elapse before any machining. Complete hardening is achieved after heating in a ventilated oven for 1 to 3 hours at 80°C (or 2 to 5 hours at 60°C for thermoformed parts). Polymerisation of Special Care Adhesive P10 is accompanied by a reduction in volume of approximately 15%. The volume of adhesive to be applied must always be greater than the volume of the joint surface cavity.

PROPERTIES OF JOINTS MADE WITH SPECIAL CARE ADHESIVE P10:

Mechanical strength is determined by traction applied to test samples formed by end-to-end bonding.

Measurements have been made using test samples heated for 4 hours at 60°C and on samples that had been left to harden naturally for 4 days at room temperature. The values below are given for guidance only and are not guaranteed.

Tensile strength:

→ After 4 days of natural hardening: 45 to 50 Mpa

→ After heating at 60°C: 48 to 53 Mpa

The principles of Responsible Care® and sustainability influence the production of printed literature for Trinseo S.A. and its affiliated companies. As a contribution towards the protection of our environments, Trinseo's printed literature is produced in small quantities and on paper containing recycled/post-consumer fiber and using 100 percent soy based ink whenever possible.

Product Stewardship

Trinseo and its affiliated companies have a fundamental concern for all who make, distribute, and use their products and for the environment in which we live. This concern is the basis for our Product Stewardship philosophy by which we assess the safety, health, and environmental information on our products so that appropriate steps may be taken to protect employee and public health and our environment. The success of our product stewardship program rests with each and every individual involved with Trinseo products – from the initial concept and research, to manufacture, use, sale, disposal, and recycle of each product.

Customer Notice

Customers are responsible for reviewing their manufacturing processes and their applications of Trinseo products from the standpoint of human health and environmental quality to ensure that Trinseo products are not used in ways for which they are not suitable. Trinseo personnel are available to answer questions and to provide reasonable technical support. Trinseo product literature, including safety data sheets, should be consulted prior to the use of Trinseo products. Current safety data sheets are available from Trinseo.

No freedom from infringement of any patent owned by Trinseo or others is to be inferred. Because use conditions and applicable laws may differ from one location to another and may change with time, the customer is responsible for determining whether products and the information in this document are appropriate for the customer's use and for ensuring that the customer's workplace and disposal practices are in compliance with applicable legal requirements. Although the information herein is provided in good faith and was believed to be accurate when prepared, Trinseo assumes no obligation or liability for the information in this document.

NOTICE REGARDING MEDICAL APPLICATION RESTRICTIONS

TRINSEO REQUESTS THAT CUSTOMERS REFER TO TRINSEO'S MEDICAL APPLICATION POLICY [HTTP://WWW.TRINSEO.COM, MEDICAL.HTM](http://www.trinseo.com/MEDICAL.HTM) BEFORE CONSIDERING THE USE OF TRINSEO PRODUCTS IN MEDICAL APPLICATIONS. THE RESTRICTIONS AND DISCLAIMERS SET FORTH IN THAT POLICY ARE INCORPORATED BY REFERENCE.

For more information on products, innovations, expertise, and other services available from Trinseo, visit www.trinseo.com, or in the U.S. contact us at +1-855-TRINSEO (+1-855-874-6736).

DISCLAIMER

TRINSEO MAKES NO WARRANTIES, EITHER EXPRESS OR IMPLIED, IN THIS DOCUMENT; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE (INCLUDING MEDICAL APPLICATIONS) ARE EXPRESSLY EXCLUDED. SINCE THE CONDITIONS AND METHODS OF USE OF THE INFORMATION AND PRODUCTS REFERRED TO ARE BEYOND TRINSEO'S KNOWLEDGE AND CONTROL, TRINSEO DISCLAIMS ANY AND ALL LIABILITY FOR LOSSES OR DAMAGES THAT MAY RESULT FROM RELIANCE ON THE INFORMATION OR USE OF THE PRODUCTS DESCRIBED HEREIN. TRINSEO MAKES NO WARRANTIES, EXPRESS OR IMPLIED, THAT THE USE OF ANY TRINSEO PRODUCT WILL BE FREE FROM ANY INFRINGEMENT CLAIMS.

GENERAL NOTICE

Any photographs of end-use applications in this document represent potential end-use applications but do not necessarily represent current commercial applications, nor do they represent an endorsement by Trinseo of the actual products. Further, these photographs are for illustration purposes only and do not reflect either an endorsement or sponsorship of any other manufacturer for a specific potential end-use product or application, or for Trinseo, or for specific products manufactured by Trinseo. If products are described as "experimental" or "developmental": (1) product specifications may not be fully determined; (2) analysis of hazards and caution in handling and use are required; (3) there is greater potential for Trinseo to change specifications and/or discontinue production, and (4) although Trinseo may from time to time provide samples of such products, Trinseo is not obligated to supply or otherwise commercialize such products for any use or application whatsoever.

For additional information not covered by the content of this document or to ensure you have the latest version of this document available, please refer to our website at www.trinseo.com/contact.

Follow us at:

